



# STANDARD INSTALLATION INSTRUCTIONS FOR O'HAGIN'S CLAY TILE VENTS


## Model "S" Clay Tile




**1. MARK** Centered between layout lines and aligned approximately as shown on exposure lines.




**2. CUT** Set blade to thickness of sheathing.




**3. SEAL** Flanges with mastic.



**4. SECURE** At 4-inch centers using roofing nails of sufficient length to penetrate sheathing.




**5. FLASH** With peel and stick or slip under felt (see Note below).




**6. INSTALL** And secure vent cover with roofing nails of sufficient length to penetrate sheathing. Bend the wind clip hook under the preceding course of tile and adjust for head lap.


## Model "M" Clay Tile




Mark and cut vent opening as shown. Align the bottom of the cutout 1/2-inch to 1-inch above the pan tile layout line as shown.



Seal, secure and flash (see Note below) as shown. Apply the field tile up to the primary vent, nailing tile wire into place. (Peel and stick flashing).



Apply field tile around the primary vent and install the vent tile (the vent tile takes the place of two caps and one pan tile). Secure into place (see Note below). Installation is now complete.



## Flat Clay Tile

Tile is inserted between louvered top sheet and bottom flanged sheet from the bottom. Remove 2 to 3 inches of the batten lug on either side of the vent for proper fit. For clarity, the last course is not shown on the detail.


Bend the wind clip hook under the preceding course of tile and adjust for head lap. The vent tile unit takes the place of two (2) field tiles.

### NOTE:


1. Peel and stick using one strip at top and one at bottom (27" x 3" each); one strip on each side (13" x 3"); must hold waterproof membrane a minimum of 3/4" away from the raised lip, top and sides; or apply bib over method with locally approved felt.
2. Like materials must be used (i.e. copper vent must use copper wire and nails).
3. Do not install vents below or adjacent to valleys or other areas of concentrated water runoff.
4. Standard installation at 3:12 pitch or greater.

\* For more information regarding snow and high velocity wind applications, contact O'Hagin's, Inc.


## Modelo "S" Loseta de Barro




**1. MARQUE** Las líneas guía centradas y alineadas de la manera que se muestra en las líneas expuestas.




**2. CORTE** Ajuste la navaja al grosor de la superficie.




**3. SELLE** Las orillas con sellador especial.



**4. ASEGURE** Cada 4 pulgadas con clavos para techo, de suficiente largo para que penetren todas las capas.



**5. NIVELE** Con cinta y una madera, o una junta debajo del fieltro (vea la nota que sigue).




**6. INSTALE** Y asegure la cubierta de la ventila con clavos suficientemente largos para penetrar todas las capas. Doble el gancho bajo la siguiente línea de losetas y alinee con la franja superior.


## Modelo "M" Loseta de Barro




Marque y corte la abertura de la ventila. Alinee la parte baja de la abertura a 1/2 o 1 pulgada arriba de la línea guía de la loseta como se muestra.



Selle, asegure y nivele (vea la Nota de abajo) como se muestra. Coloque las losetas hasta la ventila primaria, clavando el alambre de las losetas en su lugar. (Despegue y aplique la cinta).



Aplique las losetas alrededor de la ventila e instale la ventila de loseta (La ventila toma el lugar de dos tapas y de una teja). Asegure en su lugar (vea la Nota de abajo).



## Loseta de Barro Plano

La loseta se inserta entre la capa de arriba y la orilla de la base. Elimine de 2 a 3 pulgadas de las dos maderitas usadas a los lados para un ajuste adecuado. Para mayor claridad, el último paso no se muestra con detalle. Doble el gancho bajo la siguiente línea de losetas y alinee con la franja superior. La ventila de loseta ocupa el lugar de dos (2) losetas normales.

### NOTA:

1. Despegue y adhiera usando una madera encima y otra abajo (27" x 3" cada una); y una a cada lado (13" x 3"); de vera sostener la membrana repelente a el agua un mínimo de 3/4" lejos del labio alzado, arriba y los lados; o aplique encima una junta de fieltro aprobada en su localidad.
2. Materiales semejantes deben ser usados (por ejemplo para una ventila de cobre se debe usar alambre y clavos de cobre).
3. No instale los ventiladores debajo o al lado de los valles o a otras areas de la salida concentrada del agua.
4. Instalacion estandar en la echada de 3:12 o mayor.

\* Para más información acerca de instalaciones para nieve y para velocidad de vientos contacte a la compañía de O'Hagin's.